

# IMPORTANT SAFETY INSTRUCTIONS READ CAREFULLY

- 1. Check for structural integrity and proper connecting hardware before every use. Replace damaged or missing parts or fasteners immediately.
- 2. Safety/Warning labels must be clearly visible.
- 3. Securely anchor moveable soccer goals at ALL times.
- 4. Always instruct players, managers, coaches, trainers, teachers, maintenance and all other personnel who might come in contact with the goal, on the safe handling of and potential dangers associated with moveable soccer goals.
- 5. Always exercise extreme caution when moving goals and allow adequate manpower to move goals of varied sizes and weights. Moveable soccer goals should only be moved by authorized personnel.
- 6. NEVER allow anyone to climb on the net or goal framework.
- 7. Moveable soccer goals should only be used on LEVEL fields, NEVER on a slope or hill area.
- 8. Remove nets when goals are not in use.
- 9. Most of the tip-over injuries occurred when goals were unattended. Anchor or chain one goal to another, or to nearby fence posts, dugouts, or any other similar sturdy fixture when not in use. If this is not practical, store moveable soccer goals in a place where children cannot have access to them.
- 10. Fully disassemble goals for seasonal storage.



### **INSTRUCTION FOR 10B2601 STEEL ANCHOR WEIGHTS**


- 1. Set goal in desired location.
- 2. Insert 2 weights (B) into each weight bag (A) and close bag. See figure 1.
- 3. Attach two weight bags to the rear of each goal using chain (C) and snap link (D). See figure 2.
- 4. With chains and weights properly connected to goal, see figure 3 for test procedures to assure that goal has been anchored properly.

CAUTION: GOALS MUST BE PROPERLY ANCHORED OR STORED AT ALL TIMES.

#### \*\*\*CAUTION\*\*\*

This goal has been designed to be used for the game of soccer only. Goal post must be anchored AT ALL TIMES and shall be secured against tilting. Do not climb on the net or goal framework at anytime! All fastenings must be checked to insure they are fully tightened before and after each use of this product. Goal posts not in use must be disassembled and properly stored in a safe secure area. (See Guidelines for Moveable Soccer Goal Safety, included.) Assembled goal posts should not be left unattended. Remove nets when goals are not in use. Do not use this equipment in the threat of high winds. Goal post should be checked for safety before and after each use. All warning and safety labels included with this product must be visible at all times. Any modifications to this or any Kwik Goal product will void any and all warranties.


Parts List  A) Weight Bag  B) Weight  C) Chain  D) Snap Link	(2) (4) (2) (2)		
		Weight Bag (A)	Weight (B)
		Chain (C)	Snap Link (D)



## \*\*\*CAUTION\*\*\*

This goal has been designed to be used for the game of soccer only. Goal posts must be anchored AT ALL TIMES and shall be secured against tilting. Do not climb on the net or goal framework at anytime! All fastenings must be checked to insure they are fully tightened before and after each use of this product. Goal posts not in use must be disassembled and properly stored in a safe secure area. (See Guidelines for Moveable Soccer Goal Safety, included.) Assembled goal posts should not be left unattended. Remove nets when goals are not in use. Do not use this equipment in the threat of high winds. Goal posts should be checked for safety before and after each use. All warning and safety labels included with this product must be visible at all times. Any modifications to this or any Kwik Goal product will void any and all warranties.

Fig. 2




## \*\*\*CAUTION\*\*\*

This goal has been designed to be used for the game of soccer only. Goal posts must be anchored AT ALL TIMES and shall be secured against tilting. Do not climb on the net or goal framework at anytime! All fastenings must be checked to insure they are fully tightened before and after each use of this product. Goal posts not in use must be disassembled and properly stored in a safe secure area. (See Guidelines for Moveable Soccer Goal Safety, included.) Assembled goal posts should not be left unattended. Remove nets when goals are not in use. Do not use this equipment in the threat of high winds. Goal posts should be checked for safety before and after each use. All warning and safety labels included with this product must be visible at all times. Any modifications to this or any Kwik Goal product will void any and all warranties.

After Installing anchoring system that has been chosen for securing goal to field Surface:

- 1. Clear all persons of a minimum of 50 ft. radius surrounding goal.
- 2. Apply a horizontal pull force of 242 lb. at the top of the front and center of the crossbar for 60 seconds +10 -0 seconds, full safety precautions must be taken while performing this test.
- 3. Determine if unit tilts or does not return to its original position.
- 4. If unit tilts or does not return to its original position use alternate anchoring system.



#### \*\*\*CAUTION\*\*\*

This goal has been designed to be used for the game of soccer only. Goal posts must be anchored AT ALL TIMES and shall be secured against tilting. Do not climb on the net or goal framework at anytime! All fastenings must be checked to insure they are fully tightened before and after each use of this product. Goal posts not in use must be disassembled and properly stored in a safe secure area. (See Guidelines for Moveable Soccer Goal Safety, included.) Assembled goal posts should not be left unattended. Remove nets when goals are not in use. Do not use this equipment in the threat of high winds. Goal posts should be checked for safety before and after each use. All warning and safety labels included with this product must be visible at all times. Any modifications to this or any Kwik Goal product will void any and all warranties.